

Smart Door Lock with Camera

Download the application

1. Download **Orange Smart Life JO** application

2. Open the application

3. Register using your e-mail, as the user alone is responsible for protecting the username and password for Orange Smart Life JO application, and we recommend not to share the username and password with anyone. Orange technical team will be responsible for providing setup and configuration support for the devices

4. Select (Get a code); the verification code will be sent to your e-mail

5. Fill out the six-digit code in the space provided on the application

6. Enter your password

7. Before setting up any device, you must activate the GPS feature from your mobile device in order to be connected to your wireless network (Connect to the 2.4GHz network)

IMPORTANT NOTES:

1. Install and test the lock with the door open to avoid being locked out.
2. DO NOT install the batteries before installing the lock!
3. Follow the instructions in sequential order!
4. Please use an AA Alkaline Battery and don't use a Lithium Battery or Rechargeable Battery.
5. Please replace the battery when you have a low-wattage alarm.
6. Read this manual carefully before installation and keep it for future reference.
7. Make sure the package contains all the parts mentioned below:

No.	Name	QTY
1	Exterior Assembly	1
2	Interior Assembly	1
3	Mortise	1
4	Rubber Plate	2
5	User Manual	1
6	Strike & Strike Box	2
7	Mechanical Key	2
8	Pin of spindle	1
9	Sliding Screw A	1
10	IC Card	3
11	Screw B	4
12	Screw C	4
13	Screw D	1
14	Screw E	1
15	Square Shaft	1
16	Screw Casing	2
17	Screw Cover	1

Electronic Locking Button:

Locked - UnLock

1. The button turning "red" status: The lock is in a "locked" status. It cannot be opened outside except by the Master Admin or the mechanical key. Other unlocking methods will result in a sound indicating that "the door is locked" when attempting to open it.

2. The button turning "green" status: Administrators and ordinary users can unlock from the outside.

Installing the device:

a. Adjust the Handles' Direction

Notice: Adjust the handle according to the direction you open the door.

For Exterior Assembly:

1. Loosen the screw
2. Adjust the door handle direction
3. Tighten the screws after adjusting the handle direction and complete.

For Interior Assembly:

4. Loosen the screw
5. Adjust the door handle direction
6. Tighten the screws after adjusting the handle direction and complete.

Installation Diagram:

Step 1 Install Mortise

- Install Mortise into the door with Screw C and fix it. (Refer to step 1)

Step 2 Install Exterior Assembly

1. Install the waterproof rubber plate to exterior assembly. (Refer to step 2)
2. Install square shaft into spindle hub. Make sure to keep the arrow down (Refer to steps 3, 4, 5)
3. Install exterior assembly with screw castings. (Refer to steps 6 and 7)
4. Install exterior assembly. (Refer to step 8)

Step 3 Install Interior Assembly


1. Install the waterproof rubber plate to interior assembly and loosen the battery cover screws. (Refer to steps 9,10)
2. Connect the wire. (Refer to steps 11, 12)
3. Secure the mounting plate with screw D and screw E. (Refer to steps 13 and 14)

Step 4 Install batteries

1. Insert 4 AA alkaline batteries. (Refer to step 15)
2. Install the battery cover. (Refer to step 16)
3. Installation complete.

Notes:

- Press on "*" to Cancel, Exit and Delete.
- Press on "#" to Confirm and End.



1. Add Admin

Code: 1- 5#
Choose 1 number from 1 to 5 followed by #

2. Add users

Code: 6-180#

3. Delete By Code

Input code to be deleted

4. Delete By Type

1. Fingerprint
2. Card
3. Pin code

For each option, same steps need to be repeated from the beginning

Reconfirm Successful

Device configuration through the Orange Smart Life JO app:

System Initialization

1. Open the back panel cover, press and hold the "Reset" button then install the battery.
2. Release the reset button after hearing 6 beeps
3. Initialization succeeded. The Master Password is restored to "123456".

Add Admin (Please press # after each step)

1. Press "1".
2. Enter the settings menu after verifying the administrator (the initial administrator).
3. Enter password: 123456.
4. Press "1" to enter the user management menu.
5. Press "1" to add the administrator.
6. Press any number from 1-5 to represent administrator code.
7. Press "1" to add fingerprint.
8. Press "2" to add card.
9. Press "3" to add passcode.

Pair the lock in the APP

- a. Press "2#" on the lock to authenticate the administrator.
- b. Number 5 starts flashing, meaning the lock enters network configuration state.
- c. Tap "Add Device" on the Home Page or + in the upper right corner of the page.

Attention: you should be added as admin first

- d. Click "Lock (Wi-Fi)", enter the Wi-Fi password, and connect the door lock. (It can only connect to 2.4G Wi-Fi.)
- e. Adding success: the voice prompt "operation successful" and rename your lock.
- f. Adding failure: the keypad light no. 5 on the keyboard is not lit, and the timeout voice prompt "failed."

Setup Code

1. How to set Passage Mode (the lock is always on "unlock" condition, no need for verification): After verifying unlocking and ensuring the keypad light is on, press "0" for 3 seconds, and then Passage Mode comes into effect.
2. How to set Auto-Lock (can be set by 5s, 10s, 15s, 20s)
 - a. After unlocking and the keypad lights up, press "1" for 3 seconds, then Auto-Lock by 5s comes into effect.
 - b. After unlocking and the keypad lights up, press "2" for 3 seconds, then Auto-Lock by 10s comes into effect.
 - c. After unlocking and the keypad lights up, press "3" for 3 seconds, then Auto-Lock by 15s comes into effect.
 - d. After unlocking and the keypad lights up, press "4" for 3 seconds, then Auto-Lock by 20s comes into effect.

But if you DO NOT want Passage mode, then set the Auto-Lock like the above steps.

Remote Unlock

- a. Click on the App homepage to enter the corresponding door lock page.
- b. Door lock keyboard, press "#" to request remote lock picking.
- c. The mobile APP will receive the application information and slide to unlock.
- d. The app receives a video request, if you want to view the real-time video, please click the play button, or you can directly slide to unlock
- e. Real-time video intercom can be performed, and Mute, Meta, shots, and Record can also be used during the video process.
- f. 300 free videos per month
- g. Videos of one minute regrets automatically disconnect the video.

Online Password Function

When a visitor visits your office or home, you can generate a temporary password with a valid time period, refer to the below operation steps:

1. Temporary Password
2. Online Password: Time-Limited Password
3. Add
4. Create Time-Limited Password: Generate Randomly on 7-Digit Password window.

Enter the password on the lock keyboard, and don't forget to enter "#" after passcode to confirm unlocking.

Offline Password Function

There is a one-time password and a time-limited password for offline type passwords.

You can choose to generate the one-time password as follows:

1. Temporary password (Online/Offline Password)
2. One-Time Password
3. Create One-Time Password
4. Obtain Password
5. Done

It is only valid for 6 hours, and time-limited password within 24 hours before it expires

Please use this password on the lock before it expires

Alarm

1. Automatically report after an alarm occurs. The report types include doorbell calls, tamper-proof alarms, low-voltage alarms, and validation error alerts.
2. You can view a short video when the doorbell is triggered.

Record

After opening the door, an opening record will be recorded. If the opening method has not been bound, you can click to bind the user.

1. Click on the added user, you can edit the corresponding user opening information of a user.
2. The lock and the app are synchronized through cloud information: Select the lock opening information that has been synchronized to the cloud and bind it to the username. When you open the lock in this way later, the lock opening record of the App will show the lock opening of this user. But, if the user information is deleted on the App, the user can still open the door, and it must be deleted on the lock to be effective.

Reset the Lock

Please note that all data will be erased if you reset your lock to factory default.

Replace Batteries

Please use 4 high-quality alkaline AA batteries for replacement when the battery is dead.

5V Emergency Power

A Micro USB interface is used to connect a regular 5V power bank to activate the lock in case the battery is dead.

Note: The Micro USB interface is only used for emergency unlocking and cannot be used for battery charging.

Emergency Key Unlock

The emergency key can be used when the battery is dead.

Note: Keep at least one key outside of your house so you can get it to unlock in case of emergency.

Anti-peep Keypad

The lock supports up to 16-digit Vague Code. Just enter any 16-digit code, as long as a correct code is included in what you entered, you can open the door.



قفل الباب الذكي مع الكاميرا



تحميل التطبيق

1. حمل تطبيق Orange Smart Life Jo



افتح التطبيق

1. قم بالتسجيل باستخدام بريدك الإلكتروني، حيث إن المشترك وحده هو المسؤول عن حماية اسم المستخدم وكلمة المرور الخاصة بتطبيق Orange Smart Life Jo وينصح بعدم مشاركتها مع أي شخص. الفريق الفني الخاص بـ Orange سوف يكون مسؤولاً فقط عن تقديم خدمات ضبط وإعادة تهيئة الأجهزة في حال طلب المساعدة
2. قم باختيار (الحصول على رمز) وسيصلك رمز التحقق على بريدك الإلكتروني
3. قم بتعيين الرمز المكوّن من ست خانات في المكان المخصص على التطبيق
4. قم بإدخال الرقم السري الخاص بك
5. قبل ضبط وإعداد أي جهاز، يجب تفعيل خاصية الموقع الجغرافي من جهازك الخلوي ليتم الربط على شبكة الإنترنت اللاسلكية الخاصة بك (اشترك على شبكة 2.4 جيجا هيرتز)

- ### معلومات مهمة
1. قم بتثبيت القفل وتجربته مع فتح الباب لتجنب قفله
 2. لا تقم بتثبيت البطاريات قبل تثبيت القفل
 3. اتبع التعليمات بالترتيب التسلسلي
 4. يرجى استخدام بطارية AA وعدم استخدام بطارية ليثيوم أو بطارية قابلة للشحن
 5. يرجى استبدال البطارية عندما يظهر لك إشعار بانخفاض البطارية
 6. اقرأ دليل التشغيل جيداً قبل التركيب واحتفظ به للرجوع إليه مستقبلاً
 7. تأكد من أن العلية تحتوي على جميع الأجزاء المذكورة أدناه:

الرقم	الاسم	الكمية
1	الجزء الخارجي	1
2	الجزء الداخلي	1
3	القفل	1
4	لوحة مطاطية	2
5	دليل التشغيل	1
6	قاعدة التثبيت	2
7	المفتاح الميكانيكي	2
8	الدبوس	1
9	المسمار A	1
10	البطاقة الذكية	3
11	المسمار B	4
12	المسمار C	4
13	المسمار D	1
14	المسمار E	1
15	رمج مربع	1
16	غلاف المسمار	2
17	غطاء لولبي	1

- ### زر القفل الإلكتروني:
1. قم بتحويل الزر إلى اللون الأحمر:

1. قم بتثبيت اللوحة المطاطية المقاومة للماء على الجزء الخارجي. (راجع الخطوة 2)
2. قم بتثبيت الزمان المربع في محور المغزل. تأكد من إبقاء السهم للأسفل (راجع الخطوات 3, 4, 5)
3. قم بتثبيت التجميع الخارجي باستخدام غلاف المسمار. (راجع الخطوتين 6 و 7)
4. قم بتثبيت الجزء الخارجي. (راجع الخطوة 8)

1. يتحول الزر إلى اللون الأحمر:
2. يمكن للمسؤولين والمستخدمين العاديين فتح القفل من الخارج تركيب الجهاز:


- ### ملاحظة:
- اضبط المقيض بحسب اتجاه فتح الباب
1. قم بشفط اتجاه مقيض الباب
 2. اضبط اتجاه مقيض الباب
 3. قم بشفط البراني بعد ضبط اتجاه المقيض وإكمالها

- ### للقطع الخارجية:
1. قم بشفط المسمار
 2. قم بتثبيت لوحة التثبيت باستخدام المسمار D والمسمار E. (راجع الخطوتين 13 و 14)


- ### للقطع الداخلية:
1. قم بشفط المسمار
 2. اضبط اتجاه مقيض الباب
 3. قم بشفط البراني بعد ضبط اتجاه المقيض وإكمالها

- ### خطوات التركيب:
- الخطوة 1 تركيب القفل
- قم بتثبيت القفل في الباب باستخدام المسمار C وتبته. (راجع الخطوة 1)


- ### الخطوة 2 التركيب الخارجي
1. قم بتثبيت اللوحة المطاطية المقاومة للماء على الجزء الخارجي. (راجع الخطوة 2)
 2. قم بتثبيت الزمان المربع في محور المغزل. تأكد من إبقاء السهم للأسفل (راجع الخطوات 3, 4, 5)
 3. قم بتثبيت التجميع الخارجي باستخدام غلاف المسمار. (راجع الخطوتين 6 و 7)
 4. قم بتثبيت الجزء الخارجي. (راجع الخطوة 8)



- ### الخطوة 3 التركيب الداخلي
1. قم بتثبيت اللوحة المطاطية المقاومة للماء على الجزء الداخلي وقم بشفط براني غطاء البطارية. (راجع الخطوات 9, 10)
 2. قم بتوصيل السلك. (راجع الخطوات 11, 12)
 3. قم بتثبيت لوحة التثبيت باستخدام المسمار D والمسمار E. (راجع الخطوتين 13 و 14)



- ### الخطوة 4 تركيب البطاريات
1. أدخل 4 بطاريات مفاصل AA. (راجع الخطوة 15)
 2. قم بتثبيت غطاء البطارية. (راجع الخطوة 16)
 3. تم التركيب بنجاح.



- ### ملاحظات:
1. لا يمكن للحذف حسب النوع حذف معلومات مستخدم الإدارة، ولا يمكن حذف مستخدم الإدارة إلا عن طريق الرمز.
 2. يتطلب وضع تأكيد المستخدم المزوج مصادقة مستخدمين عاديين. لا يتأثر المسؤول بهذا ويمكنه فتح القفل مباشرة. لن تكون مصادقة المستخدم المزوج فعالة عندما تكون في الحالة الأولية.
 3. يمكن فتح القفل باستخدام الرمز الافتراضي 123456 يليه # في الوضع التجريبي.
 4. عندما يكون الجهد أقل من 4.8 فولت، سيبه القفل تلقائياً في كل مرة. بعد التنبيه، يمكن فتح القفل 200 مرة. بعد عدد من المرات، سيكون وقت التأخير لكل فتح قفل هو ثابتهين.
 5. أبق القفل قريباً من جهاز Wi-Fi.

تعريف الجهاز على تطبيق Orange Smart Life Jo

- ### ضبط النظام
1. افتح غطاء اللوحة الخلفية، واضغط مع الاستمرار على زر "إعادة الضبط" بعد ذلك قم بتركيب البطارية.



2. اترك زر إعادة الضبط بعد سماع 6 تنبيهات.
3. تم ضبط النظام بنجاح. تتم استعادة كلمة المرور الرئيسية إلى "123456".

إضافة مسؤول (يرجى الضغط على "#" بعد كل خطوة)

1. اضغط على "1"
2. قم بالدخول إلى قائمة الإعدادات بعد التحقق من المسؤول (المسؤول الأولي).
3. أدخل كلمة المرور: 123456
4. اضغط على "1" للدخول إلى قائمة إدارة المستخدم.
5. اضغط على "1" لإضافة المسؤول.
6. اضغط على أي رقم من "1-5" ليتمثل رمز المسؤول.
7. اضغط على "1" لإضافة بصمة الإصبع.
8. اضغط على "2" لإضافة البطاقة.
9. اضغط على "3" لإضافة رمز المرور.

إضافة الجهاز على تطبيق Orange Smart Life Jo

1. اضغط على "2" ثم "#"
2. اضغط على "2" ثم "#"
3. اضغط على "2" ثم "#"
4. إنشاء كلمة مرور مؤقتة: عيّن كلمة المرور عشوائية مكونة من 7 أرقام.
5. اضغط على "+" في الزاوية اليمنى العليا من الصفحة الرئيسية ثم اضغط على "إضافة جهاز"

- ### تنبيه:
- يجب إصافتك كمسؤول أولاً
- اختر الجهاز
 - انقر على "Lock (Wi-Fi)" وأدخل كلمة مرور شبكة الإنترنت، وقم بتوصيل قفل الباب. (يتم للاتصال بشبكة 2.4 Wi-Fi جيجا هيرتز فقط)
 - إضافة بطاقة: يتم سماع تنبيه صوتي لـ "العملية ناجحة"
 - إضافة قاشة: رقم "5" على لوحة المفاتيح غير مضاء، يتم سماع تنبيه صوتي لـ "العملية فاشلة".

رمز الإعداد

1. كيفية ضبط وضع المرور (القفل يبقى في حالة "فتح" دائماً، بدون الحاجة للتأكد): بعد التحقق من فتح القفل والتأكد من المؤشرات على لوحة المفاتيح، اضغط على الرقم "0" لمدة 3 ثوانٍ، وبذلك يتم تفعيل وضع المرور.
2. كيفية ضبط القفل التلقائي (يمكن ضبطه لمدة 5 ثوانٍ، و10 ثوانٍ، و15 ثانية، و20 ثانية)

- بعد إلغاء القفل وإضائة لوحة المفاتيح، اضغط على "1" لمدة 3 ثوانٍ، تم يدخل القفل التلقائي بمقدار 5 ثوانٍ حيز التنفيذ.
- بعد إلغاء القفل وإضائة لوحة المفاتيح، اضغط على "2" لمدة 3 ثوانٍ، تم يدخل القفل التلقائي بمقدار 10 ثوانٍ حيز التنفيذ.

- بعد إلغاء القفل وإضائة لوحة المفاتيح، اضغط على "3" لمدة 3 ثوانٍ، تم يدخل القفل التلقائي لمدة 15 ثانية حيز التنفيذ.
- بعد إلغاء القفل وإضائة لوحة المفاتيح، اضغط على "4" لمدة 3 ثوانٍ، تم يدخل القفل التلقائي لمدة 20 ثانية حيز التنفيذ.

ولكن إذا كنت لا تريد وضع المرور، فقم بتعيين القفل التلقائي بالخطوات المذكورة أعلاه.

فتح القفل عن بُعد

- انقر على الصفحة الرئيسية للتطبيق للدخول إلى صفحة قفل الباب
- من لوحة مفاتيح قفل الباب، اضغط على "#"
- سيتلقى تطبيق الهاتف المحمول معلومات الطلب، اسحب لفتح القفل.
- يتم طلب التطبيق للفيديو، إذا كنت ترغب في مشاهدة الفيديو في الوقت الحقيقي، يرجى النقر على زر التشغيل، أو يمكنك السحب مباشرة لفتح القفل.
- يمكن إجراء اتصال داخلي فوري عبر الفيديو، ويمكن استخدام Meta and Mute واللقطات والتسجيل أثناء عملية الفيديو.
- 300 فيديو مجاني شهرياً
- مقاطع الفيديو تبلغ مدتها دقيقة واحدة.

تعين كلمة المرور عبر الإنترنت

1. عندما يقوم زائر بزيارة مكتبك أو منزلك، يمكنك إنشاء كلمة مرور مؤقتة، اتبع خطوات التشغيل التالية:
 2. كلمة المرور المؤقتة
 3. كلمة المرور عبر الإنترنت: كلمة مرور مؤقتة
 4. إنشاء كلمة مرور مؤقتة: عيّن كلمة المرور عشوائية مكونة من 7 أرقام.
- أدخل كلمة المرور على لوحة مفاتيح القفل، وأدخل "#"

- ### تعيين كلمة المرور بدون إنترنت
- توجد كلمة مرور لمرة واحدة وكلمة مرور مؤقتة بدون الحاجة للاتصال بالإنترنت، يمكنك اختيار إنشاء كلمة المرور لمرة واحدة كما يلي:
1. كلمة المرور المؤقتة (كلمة المرور عبر الإنترنت/غير متصل)
 2. كلمة المرور لمرة واحدة
 3. إنشاء كلمة مرور لمرة واحدة
 4. الحصول على كلمة المرور
 5. تم

لمحة المفاتيح (Anti-peep)

- يدعم القفل إدخال رمز سري إلى ما يصل إلى 16 رمزاً. ويجب إدخال 16 رمز بالطريقة الصحيحة حتى يتم فتح الباب.

التنبيه

1. الإيلاغ التلقائي بعد حدوث الإنذار. تتضمن أنواع التقارير مكالمات جرس الباب، والإنذارات، وتنبيهات الخطأ.
2. يمكنك مشاهدة مقطع فيديو عند تشغيل جرس الباب.

التسجيل

- بعد فتح الباب سيتم تسجيل فتح الباب، إذا لم يتم شريك طريقة الفتح، فيمكنك النقر لشبك المستخدم.

1. اضغط على المستخدم المضاف، ويمكنك تعديل معلومات فتح المستخدم.
2. تتم مزامنة القفل والتطبيق من خلال المعلومات عبر cloud، حدد معلومات فتح القفل التي تمت مزامنتها واشكها باسم المستخدم. عند فتح القفل بهذه الطريقة لاحقاً، سيُظهر سجل فتح القفل الخاص بالتطبيق فتح القفل لهذا المستخدم. في حال تم حذف معلومات المستخدم من التطبيق، فلا يزال بإمكان المستخدم فتح الباب، ويجب حذفها على القفل لتكون فعالة.

إعادة ضبط القفل

- يرجى ملاحظة أنه سيتم مسح جميع البيانات إذا قمت بإعادة ضبط القفل.

استبدال البطاريات

- يرجى استخدام 4 بطاريات فلوية AA عالية الجودة.

تشغيل الطوارئ 5 فولت

- يتم استخدام واجهة Micro USB لتوصيل الباور بانك 5 فولت لتشغيل القفل في حالة نفاذ البطارية.

ملاحظة:

- تُستخدم واجهة Micro USB فقط لمنع القفل في حالات الطوارئ ولا يمكن استخدامها لشحن البطارية.

- ### فتح مفتاح الطوارئ
- يمكن استخدام مفتاح الطوارئ في حال نفاذ البطارية.
- ملاحظة: احتفظ بمفتاح واحد على الأقل خارج منزلك حتى تتمكن من فتح القفل في حالة الطوارئ.

لمحة المفاتيح (Anti-peep)

- يدعم القفل إدخال رمز سري إلى ما يصل إلى 16 رمزاً. ويجب إدخال 16 رمز بالطريقة الصحيحة حتى يتم فتح الباب.